## Managing EMI in Class D Audio Applications

### **EMI - The Basics**

Electromagnetic Interference (EMI) is an unwanted disturbance caused in an electrical circuit by electromagnetic radiation emitted from an external source. The disturbance may interrupt, obstruct, or otherwise degrade the effective performance of the circuit.

In today's portable and consumer applications, space has become a premium, and engineers are often required to eliminate enclosures and shielding, and suppress EMI and noise through other means such as better segregation at the circuit level. Smaller space and higher functionality require highdensity PCBs, and the use of wafer-scale packaging with tiny PCB design rules makes EMI more of a concern.

EMI encompasses two aspects. Emissions refer to the scope to which equipment generates radiated noise. Susceptibility is the scope to which equipment is affected by emissions generated from other electromagnetic waves. The degree to which a designer controls unintended emissions may make the task of susceptibility easier. Emissions are generally classified as radiated and conducted emissions. Radiated emissions leave a circuit board, trace, or wire, and propagate through the air in the form of electromagnetic waves to interfere with a nearby receiver. It is important to note that a "receiver" refers to any circuit whose operation can be affected adversely by the reception of electromagnetic energy such as a PCB trace or even the lead of an IC. Conducted emissions refer to energy which escapes, or is conducted, out of a circuit through wires or cables. Conducted emissions may cause problems directly or manifest themselves as radiated emissions.

In order to understand emissions, it is important to understand antennas. In *Figure 1*, the well-known physical relationship between wavelength and frequency is shown:

$$\lambda = \frac{\text{Velocity of Light}}{\text{Frequency x } \sqrt{\epsilon_r}} = \frac{300}{f \text{ (MHz) x } \sqrt{\epsilon_r}}$$
$$\epsilon_r \text{ is the relative permittivity}$$

30041502

### FIGURE 1. Wavelength as a Function of Frequency

The shortest length required to be an efficient antenna is  $\lambda/4$ . In the case of air, permittivity is 1, but in the case of FR4 or glass-epoxy PCBs, permittivity is reduced to approximately 4.8. The effect causes a signal traveling a trace to slow once it reaches the dielectric gradient created by the FR4 material, causing essentially, a "wavelength- shortening" effect. For example: A 200 MHz signal has a quarter wavelength in air of 16.7 cm.

In an inner-layer PCB trace, it is:  $16.7/4.8^{(1/2)} = 7.6$  cm.

National Semiconductor Application Note 1737 Bill McCulley November 2, 2007



A PCB trace can act as an unintentional antenna even at lengths shorter than  $\lambda/4$ , increasing both emissions and susceptibility. Surface traces also exhibit this wavelength shortening effect, as one side of the dielectric serves to change the overall permittivity of the transmission.

Unintended antennas, such as PCB traces, are the key culprit behind radiated noise in digital systems. As we will see, the Class D audio amplifier is, in essence, a digital system from the perspective of radiated emissions. One key principle underlying electromagnetism is that of reciprocity. A flow of current can create an electric field, and a change in electric flux can induce a current to flow. Likewise, an antenna that is good for receiving is also good for transmitting. If any of the dimensions of an unintentional antenna approach quarter wavelength at the frequency at which that antenna is excited by noise current, radiated emissions can be expected.



FIGURE 2. Common Antennas

These are two common antenna designs, the simple dipole and whip, shown in *Figure 2*. An interesting observation is that the whip is essentially one half of a dipole with the horizontal ground essentially being induced to act as the other half of a dipole.

Antennas are intended to transmit and receive signals through the radiation of electric energy. But, as illustrated in *Figure 3, unintended* antennas in circuit boards can include:

- Long traces
- Vias
- · Component leads and pins
- Unpopulated PCB board connectors and headers



FIGURE 3. Unintended Antennas in PCBs

An unterminated surface trace or an unterminated buried trace can become an unintended whip antenna. Segments of traces at different RF potential due to poor layout can become unintentional dipole antennas. Also, the conductive layers of the PCB can act as the other leg of a dipole antenna with the plane itself being coupled into the electric field.

## The Class D Audio Amplifier

The Class D audio amplifier has emerged as a popular topology for the consumer market due to its high efficiency. It modulates a high-frequency square wave by the incoming analog signal. The square wave itself could be fixed frequency, variable frequency, or simply random pulses with no fixed frequency. A low-pass filter, typically a 2-pole Butterworth, is used to filter the high-frequency content and recover the original audio signal. In "filterless" topologies, the inductance of the speaker itself is incorporated as part of the filter. One common Class D topology, Pulse Width Modulation (PWM), uses a fixed-frequency waveform and changes the duty cycle to create a moving average of the signal after a low-pass filter as seen in *Figure 4*.

The benefits of a switching topology are apparent - high efficiency, low power consumption, and small thermal designs. But increased efficiency is not without cost. In order to drive efficiencies up, a sharp, rapidly switching square wave is required. This can lead to the same undesirable artifacts that are present in digital systems as the spectral energy is highly concentrated on the edges of the square wave. Also, there will be some overshoot, causing the waveform to go beyond the maximum and minimum voltages for a short time. Overshoot creates additional high-frequency content in the output spectrum and is undesirable for EMI and audio performance.



FIGURE 4. The Class D Audio Amplifier PWM

# AN-1737

antennas encompass any route in which both forward and return currents are on a well-defined conducting path: Optimally, you will stop radiation by suppressing the source For the audio designer, it is important to consider the follow-

• Keep traces from the audio amplifier to the speaker as short as possible. PCB traces and/or wires act as antennas with significant radiation occurring once the trace length reaches  $\lambda/4$ .

To counter EMI, it is essential to include PCB floor planning

as part of the circuit design with the electrical engineer, PCB

lavout engineer, and manufacturing engineer. General PCB

Placement of decoupling capacitors between power and

ground where voltage fluctuations are determined to exist.

Power planes should be backed off from the edges of the

Avoidance of traces cut within ground or power planes -

Adequate termination of all high-frequency clock lines.

Good PCB design will avoid loop antennas. Loop

Haphazard placement of caps can exacerbate the EMI problem. References for the use of decoupling capacitors

Countering EMI

PCB

ing:

guidelines for dealing with EMI include:

are included at the end of this article.

which can create an unintended aperture

Proper filtering of PCB connectors

of current that is feeding the antenna.

For filterless Class D systems, the trace and cable length connecting the amplifier's output to the speakers will likely be the largest source of RF emissions.

The practice of placing ferrite beads in series with the loudspeakers close to the amplifier can be effective. In order to better understand the suppression mechanism of ferrite beads, it is useful to break the ferrite bead down into frequency-dependent resistive and inductive elements - R(f) and L (f) - as shown in Figure 5.

Regarding EMI suppression purposes, ferrite beads act as resistors, but because  $R_{DC} = 0$ , there is no DC voltage drop. This makes them useful in cases where frequencies of interest are significantly below 1 MHz. Also, as shown in the figure, it is important to understand that the ferrite bead is effective when considered part of a two-element voltage divider. Both Z1 and Z2 are frequency dependent. To achieve the desired function of a low-pass filter, the following relationships should be present:  $Z_2 > Z_1$  at desired frequencies and  $Z_1 > Z_2$  at noise frequencies.



### FIGURE 5. Resistance and Inductance as a Function of Frequency

The ferrite will usually serve as the series element, and the shunt element is a capacitance - either a physical capacitance or a lumped capacitance. The transfer function indicates that  $Z_1$  will increase and  $Z_2$  will decrease with frequency (1/j $\omega$ C) and that the system will be damped to the extent that resonance effects are significantly diminished. The primary difficulty with periodic square waves inherent in Class D is the concentration of energy at the harmonic intervals.

In the push to create a "guiet" low-EMI class D amplifier, one approach is to dither that frequency back and forth - or spread the spectrum of the switching so the energy at any one point in the spectrum is reduced. Compared to traditional Class D amplifiers, the spread-spectrum-modulation scheme has some key advantages. Efficiency and low THD+N are maintained, but radiated noise and EMI can be significantly reduced, as seen in Figure 6.





AN-1737

The LM48511 is a spread-spectrum-modulated class D audio amplifier. It also includes a built-in boost regulator which drives the supply voltage to 7V, increasing amplifier output power and the audio-sound pressure level compared to an unboosted amplifier. The boost regulator allows the amplifier to maintain a constant output level, even when powered from a decaying voltage source such as a battery.

The LM48511 amplifier features a logic-selectable, spreadspectrum modulator that reduces EMI, eliminating the need for output filters or chokes. As shown in *Figure 7*, the spreadspectrum modulator feeds a standard H-Bridge which drives the bridgetied-load speaker. In spread-spectrum mode, the switching frequency varies randomly by 10% around a 330 kHz center frequency, decreasing EMI emissions radiated by the speaker and associated cables and traces. Where a fixed-frequency Class D exhibits large amounts of spectral energy at multiples of the switching frequency, the spread-spectrum architecture of the LM48511 amplifier spreads that energy over a larger bandwidth, reducing peak noise power in the circuit.

Electromagnetic interference is a system-level concern, and it is essential for today's audio engineer to design with EMI in mind, including the best possible design practices and judicious choice of components and materials.



## References

- Bruce Archambeault and James Drewniak, "PCB Design for Real-World EMI Control", 2002
- David Terrell and R. Kenneth Keenen, "Digital Design for Interference Specifications", 1997
- Howard Johnson, "High-Speed Digital Design: A Handbook of Black Magic", 1993

Products		Design Support	
Amplifiers	www.national.com/amplifiers	WEBENCH	www.national.com/webench
Audio	www.national.com/audio	Analog University	www.national.com/AU
Clock Conditioners	www.national.com/timing	App Notes	www.national.com/appnotes
Data Converters	www.national.com/adc	Distributors	www.national.com/contacts
Displays	www.national.com/displays	Green Compliance	www.national.com/quality/green
Ethernet	www.national.com/ethernet	Packaging	www.national.com/packaging
Interface	www.national.com/interface	Quality and Reliability	www.national.com/quality
LVDS	www.national.com/lvds	Reference Designs	www.national.com/refdesigns
Power Management	www.national.com/power	Feedback	www.national.com/feedback
Switching Regulators	www.national.com/switchers		
LDOs	www.national.com/ldo		
LED Lighting	www.national.com/led		
PowerWise	www.national.com/powerwise		
Serial Digital Interface (SDI)	www.national.com/sdi		
Temperature Sensors	www.national.com/tempsensors		
Wireless (PLL/VCO)	www.national.com/wireless		

For more National Semiconductor product information and proven design tools, visit the following Web sites at:

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED IN CONNECTION WITH NATIONAL SEMICONDUCTOR CORPORATION ("NATIONAL") PRODUCTS. NATIONAL MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE ACCURACY OR COMPLETENESS OF THE CONTENTS OF THIS PUBLICATION AND RESERVES THE RIGHT TO MAKE CHANGES TO SPECIFICATIONS AND PRODUCT DESCRIPTIONS AT ANY TIME WITHOUT NOTICE. NO LICENSE, WHETHER EXPRESS, IMPLIED, ARISING BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT.

TESTING AND OTHER QUALITY CONTROLS ARE USED TO THE EXTENT NATIONAL DEEMS NECESSARY TO SUPPORT NATIONAL'S PRODUCT WARRANTY. EXCEPT WHERE MANDATED BY GOVERNMENT REQUIREMENTS, TESTING OF ALL PARAMETERS OF EACH PRODUCT IS NOT NECESSARILY PERFORMED. NATIONAL ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR BUYER PRODUCT DESIGN. BUYERS ARE RESPONSIBLE FOR THEIR PRODUCTS AND APPLICATIONS USING NATIONAL COMPONENTS. PRIOR TO USING OR DISTRIBUTING ANY PRODUCTS THAT INCLUDE NATIONAL COMPONENTS, BUYERS SHOULD PROVIDE ADEQUATE DESIGN, TESTING AND OPERATING SAFEGUARDS.

EXCEPT AS PROVIDED IN NATIONAL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, NATIONAL ASSUMES NO LIABILITY WHATSOEVER, AND NATIONAL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY RELATING TO THE SALE AND/OR USE OF NATIONAL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

#### LIFE SUPPORT POLICY

NATIONAL'S PRODUCTS ARE NOT AUTHORIZED FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE EXPRESS PRIOR WRITTEN APPROVAL OF THE CHIEF EXECUTIVE OFFICER AND GENERAL COUNSEL OF NATIONAL SEMICONDUCTOR CORPORATION. As used herein:

Life support devices or systems are devices which (a) are intended for surgical implant into the body, or (b) support or sustain life and whose failure to perform when properly used in accordance with instructions for use provided in the labeling can be reasonably expected to result in a significant injury to the user. A critical component is any component in a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system or to affect its safety or effectiveness.

National Semiconductor and the National Semiconductor logo are registered trademarks of National Semiconductor Corporation. All other brand or product names may be trademarks or registered trademarks of their respective holders.

Copyright© 2007 National Semiconductor Corporation

For the most current product information visit us at www.national.com



N-1737

1

National Semiconductor Americas Customer Support Center Email: new.feedback@nsc.com Tel: 1-800-272-9959 National Semiconductor Europe Customer Support Center Fax: +49 (0) 180-530-85-86 Email: europe.support@nsc.com Deutsch Tei: +49 (0) 69 9508 6208 English Tel: +49 (0) 870 24 0 2171 Français Tei: +33 (0) 1 41 91 8790 National Semiconductor Asia Pacific Customer Support Center Email: ap.support@nsc.com National Semiconductor Japan Customer Support Center Fax: 81-3-5639-7507 Email: jpn.feedback@nsc.com Tel: 81-3-5639-7560