

Epson WF-2530 LCD initialisation sequence

v1.3 7 Dec 2018

This printer was manufactured about 2012.

LCD controller similar to ST7567, but some extra instruction codes that are not in preliminary datasheet.

LCD 8 pin interface : CSB, RSTB, A0, SCLK, SDA, VDD, GND, VG

CSB	Chip select. active low, going low before the clock becomes active, and staying low for the whole period while a sequence of bytes is sent.
RSTB	Reset, hardware reset LCD, pulsed low for 85uS once after power on..
A0	Register select, asserted low to write commands, high to write data.
SCLK	Clock, 3MHz during CSB period for LCD controller.
SDA	Data, write bits clocked on rising edge of SCLK. Sent most-significant-bit first, 8 bit words, 420nS delay between bytes (clock stretched).
VDD	3.3V, logic power supply.
GND	0V
VG	LCD generated power.

From the instruction codes sent, it appears to have a Sitronix controller, like ST7567, but some extra commands. A lot of sequences are padded with no-operation (NOP) commands (code 'E3'), maybe this is because the printer uses a 32bit processor and writes out 4 bytes at a time, so pads commands to 32bits with bytes of NOP.

The control lines are also used on other parts of the front panel for controlling the front panel LEDs and scanning for keypresses. : A0 is data, SCLK is a 250kHz clock, SDA appears to be a data strobe.

LCD initialisation:

A2 A1 C0 22 E3 81 1F E5 E3 89 02 82 32 3A D3 00 E3 E3 84 2F

A2 Bias Select
A1 Horizontal display direction - reverse
C0 Vertical display direction - normal
22 Regulation Ratio – 4.0

E3 NOP
811F Set EV, adjusts V0 – 0x1F
E5

E3 NOP
89
02 Set Column Address - 02
82

```

32  Set Page Address - 02
3A  Set Page Address - 0A
D3
00  Set Column Address of RAM low byte - 0

E3  NOP
E3  NOP
84
2F  Control power - Booster ON, Regulator ON, Follower ON

```

Sends 4 'pages' of 128 bytes, but display not turned on (unlike later 4 lines that are displayed), so I don't know what this material is.

```
E3 E3 40 00 B0 10 00 E3
```

```

E3  NOP
E3  NOP
40  Set display start line - 0
00  Set Column Address of RAM low byte - 0

```

```

B0  Set Page Address - 0
10  Set Column Address of RAM hi nibble - 0
00  Set Column Address of RAM low nibble - 0
E3  NOP

```

```

00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 02 08 20 09 24 0D 00
00 00 05 D0 00 06 88 0C 02 54 46 03 78 01 01 04
02 01 00 00 04 C8 21 02 64 01 00 7C 06 00 00 00
01 9C D2 02 04 51 01 00 00 01 30 13 01 00 00 01
40 0D 0A 28 0D 02 24 00 01 28 0D 05 3C 5E 04 28
0D 00 00 00 00 6C 00 03 28 0D 00 00 00 09 90 00
00 00 00 0D 90 00 00 00 00 01 18 1A 03 38 41 03

```

```
B1 10 00 E3
```

```

B1  Set Page Address - 1
10  Set Column Address of RAM hi nibble - 0
00  Set Column Address of RAM low nibble - 0
E3  NOP

```

```

74 20 10 28 0D 00 00 00 0D A0 00 02 B8 09 00 FC
07 04 74 07 00 00 00 01 30 8A 02 98 05 00 00 00
02 98 4C 0D 28 0D 00 00 00 05 04 0D 00 00 00 01
24 00 00 00 00 01 20 03 06 28 0D 00 00 00 05 2C
03 02 28 0D 00 00 00 05 24 00 00 00 00 05 48 00
00 00 00 05 48 00 0A 4C 4B 02 88 1B 0A 6C 0B 00
00 00 01 9C 46 1A 28 0D 00 00 00 05 3C 47 00 00
00 01 1C 1D 00 00 00 05 84 0C 0A 28 0D 00 00 00

```

B2 10 00 E3

B2 Set Page Address - 2

10 Set Column Address of RAM hi nibble - 0

00 Set Column Address of RAM low nibble - 0

E3 NOP

09 CC 4D 00 00 00 01 24 06 00 00 00 01 30 0D 00
00 00 01 50 59 00 00 00 09 74 38 00 00 00 01 0C
03 16 C4 8A 00 00 00 01 10 01 07 5C 3E 00 00 00
01 58 7C 02 5D CB 01 84 09 01 00 00 01 30 04 00
00 00 00 04 00 00 C8 06 00 04 06 02 B8 00 01 00
00 05 7C 1C 05 E8 B2 03 74 4B 05 28 E4 02 4C 04
00 00 00 00 08 01 04 8C C7 01 54 01 01 B8 2C 04
6C B0 09 A0 23 02 1C 00 01 B0 15 01 00 00 03 34

B3 10 00 E3

B3 Set Page Address - 3

10 Set Column Address of RAM hi nibble - 0

00 Set Column Address of RAM low nibble - 0

E3 NOP

00 01 7C 02 00 78 06 02 50 49 07 1C 00 02 04 50
06 7C 88 02 E0 39 02 28 27 02 3C 51 02 60 E6 02
C4 01 02 64 33 06 D8 52 02 14 04 00 00 00 01 30
00 00 00 00 01 14 63 0A 24 18 01 00 00 04 58 09
00 00 00 05 48 50 02 4C 00 00 00 00 01 1C 35 00
00 00 01 A4 31 00 00 00 05 0C 03 00 00 00 02 D0
8B 02 A0 D7 01 34 00 02 AC 01 00 00 00 01 04 8C
00 00 00 02 D0 33 03 CC 05 00 4C 00 02 FC B8 04

81 22 E3 E3

8122 Set EV, adjusts V0 - 0x22

E3 NOP

E3 NOP

E3 NOP

F0 Test

D5

A2 Bias Select

A1 Set scan direction of SEG - reverse

C0 Vertical display direction - normal

22 Regulation Ratio - 4.0

E3 NOP

81 22 E3 E3
8122 Set EV, adjusts V0 – 0x22
E3 NOP
E3 NOP

E3 A6 A4 EE
E3 NOP
A6 Set LCD normal/reverse - normal
A4 Display all points ON/OFF - OFF
EE Reset Modify-Read mode

AC 00 E5 89
AC00 Set Static Indicator State - OFF
E5
89

02 82 32 3A
02 Set lower nibble of RAM column address - 0x02
82
32
3A


D3 00 84 2F
D3
00 Set lower nibble of RAM column address - 0x00
84
2F Control power - Booster ON, Regulator ON, Follower ON

40 E3 E3 E3
40 Set display start line - 0
E3 NOP
E3 NOP
E3 NOP

Display "The date and time " on line 1, takes two pages of 128 bytes.

B0 10 00 E3
B0 Set Page Address - 0
10 Set Column Address of RAM hi nibble - 0
00 Set Column Address of RAM low nibble - 0
E3 NOP

04 04 FC 04 04 00 00 FC 40 20 20 20 C0 00 00 C0
20 20 20 20 C0 00 00 00 00 00 00 00 00 C0 20 20
20 40 FC 00 00 00 A0 A0 A0 A0 C0 00 00 20 20 F8
20 20 00 00 C0 20 20 20 20 C0 00 00 00 00 00 00
00 00 00 A0 A0 A0 A0 C0 00 00 E0 40 20 20 20 C0



00
00
20
20
F8
20
20
00
00
C0
20
20
20
20
C0
00
00
00
00
00
00
00
00
00
00
00
00
A0
A0
A0
A0
C0
00
00
E0
40
20
20
20
C0
00
00
C0
20
20
20
40
FC
00
00

.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	20
.....	20
.....	F8
.....	20
.....	20
.....	00
.....	00
.....	EC
.....	00
.....	00
.....	E0
.....	20
.....	C0
.....	20
.....	20
.....	C0
.....	00
.....	00
.....	C0
.....	20
.....	20
.....	20
.....	20
.....	C0
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00

```

AF E3 E3 E3
AF   Display ON/OFF - ON
E3   NOP
E3   NOP
E3   NOP

```

```


B1 10 00 E3

```


B1 Set Page Address - 1
10 Set Column Address of RAM hi nibble - 0
00 Set Column Address of RAM low nibble - 0
E3 NOP

00 00 0F 00 00 00 00 0F 00 00 00 00 0F 00 00 07 09 09 09 09 05 00 00
00 00 00 00 00 00 07 08 08 08 04 0F 00 00 07 08 08 08 04 0F 00 00 00
00 07 08 08 00 00 07 09 09 09 09 05 00 00 00 00 00 00 00 00 07 08 08
08 04 0F 00 00 0F 00 00 00 00 0F 00 00 07 08 08 08 04 0F 00 00 00 00
00 00 00 00 00 00 07 08 08 00 00 0F 00 00 0F 00 0F 00 00 0F 00 00 07
09 09 09 09 05 00 00 00 00 00 00 00

.....	00
.....	00
████.....	0F
.....	00
.....	00
.....	00
.....	00
████.....	0F
.....	00
.....	00
.....	00
.....	00
████.....	0F
.....	00
.....	00
████.....	07
████.....	09
████.....	09
████.....	09
████.....	09
████.....	05
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
.....	00
████.....	07
.....	08
.....	08
.....	08
.....	04
████.....	0F



00
00
07
08
08
08
04
0F
00
00
00
00
00
07
09
09
09
09
05
00
00
00
00
00
00
00
07
08
08
08
04
0F
00
00
0F
00
00
00
0F
00
00



07
08
08
08
04
0F
00
00
00
00
00
00
00
00
00
00
00
00
07
08
08
00
00
0F
00
00
0F
00
0F
00
00
0F
00
00
00
07
09
09
09
09
05
00
00
00
00
00
00
00
00

AF E3 E3 E3

AF Display ON/OFF - ON

E3 NOP

E3 NOP

E3 NOP

omit some of the art

Display "1:Yes 2:No " on line 2, takes two pages of 128 bytes.

B2 10 00 E3

B2 Set Page Address - 2


10 Set Column Address of RAM hi nibble - 0

00 Set Column Address of RAM low nibble - 0

E3 NOP

```
00 04 04 FE 00 00 00 00 30 30 00 00 00 0E 30 C0
20 18 06 00 00 E0 90 90 90 90 E0 00 00 60 90 90
90 90 20 00 00 00 00 00 00 00 00 00 0C 82 42 22
1C 00 00 30 30 00 00 00 FE 08 30 C0 00 FE 00 00
E0 10 10 10 10 E0 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

```
..... 00
. | ..... 04
. | ..... 04
. | ..... FE
..... 00
..... 00
..... 00
..... 00
..... 30
..... 30
..... 00
..... 00
..... 00
..... 0E
..... 30
..... C0
..... 20
..... 18
..... 06
..... 00
..... 00
..... E0
..... 90
..... 90
..... 90
..... 90
..... E0
..... 00
..... 00
..... 60
..... 90
..... 90
..... 90
```



90
20
00
00
00
00
00
00
00
00
00
00
00
00
00
0C
82
42
22
1C
00
00
30
30
00
00
00
FE
08
30
C0
00
FE
00
00
E0
10
10
10
10
E0
00
00
00
00
00
00
00
00
00
00

..... 00

AF E3 E3 E3

AF Display ON/OFF - ON

E3 NOP

E3 NOP

E3 NOP

B3 10 00 E3

B3 Set Page Address - 3

10 Set Column Address of RAM hi nibble - 0

00 Set Column Address of RAM low nibble - 0

E3 NOP

```


40 00 00 07 40 00 40 40 06 06 00 00 00 00 40 07
40 00 40 00 00 03 04 04 44 44 02 40 00 42 C4 44
84 84 03 80 00 00 00 40 00 00 C0 C0 06 45 84 84
04 00 00 06 06 00 80 80 87 80 00 00 81 87 40 00
43 04 44 04 44 C3 00 80 00 00 00 00 00 00 00 40
00 80 00 00 80 80 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 80 00 80 80 80 80 80 80 00 40
80 00 80 80 80 40 00 00 40 00 00 40 C0 00 00

```

```

.....█. 40
..... 00
..... 00
█..... 07
.....█. 40
..... 00
.....█. 40
.....█. 40
█..... 06
█..... 06
..... 00
..... 00
..... 00
..... 00
..... 00
.....█. 40
█..... 07
.....█. 40
..... 00
.....█. 40
..... 00
..... 00
█..... 03
█..... 04
.....█. 44
█.....█. 44

```

02
40
00
42
C4
44
84
84
03
80
00
00
00
40
00
00
C0
C0
06
45
84
84
04
00
00
06
06
00
80
80
87
80
00
00
81
87
40
00
43
04
44
04
44
C3
00
80
00

.....█.	40
.....	00
.....	00
.....	00
.....█.	40
.....█	C0
.....	00
.....	00

AF E3 E3 E3

AF Display ON/OFF - ON

E3 NOP

E3 NOP

E3 NOP

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

Sequence:

After a sequence of setup commands, 4 'pages' of 128 bytes, are sent but the display is not turned on and nothing is apparent visually. On character based LCD displays I might expect a sequence like this to be defining programmable character dot matrices, but I don't know the purpose here.

Lastly two lines of text are sent and displayed :

line1 - **"The date and time settings have been reset, or are incorrect. Do you want to set them again?"**

line2 - **"1:Yes 2:No"**

Line 1 starts to scroll left after about 2 second pause. Scrolls completely off the left of display then repeats. About 9 or 10 seconds for a character to scroll from one end to the other.

The characters are 14 pixels high, on the second line of data displayed there appears to be extra data in the lower 2 'unused' bits of each displayed byte.